



Fosi Audio






GR70 User Manual

Introduction

Thank you for purchasing the VOL20 Volume Knob.

The VOL20 is a volume control knob that supports both Bluetooth and USB connectivity modes. It is crafted from durable zinc alloy, precision-engineered with CNC technology, and finished with a high-temperature baked enamel coating for excellent durability and texture. It features built-in RGB ambient lighting with customizable colors and four lighting modes. The VOL20 allows for quick volume adjustments, remote control of music playback (play/pause, previous track, next track), and is plug-and-play without requiring additional driver or software downloads. With the VOL20, enjoy enhanced convenience and efficiency for desktop operations.



① Light Mode Button:

Single-click to toggle between light modes: Constant On mode / Light Off mode / Auto Off after 5 seconds / Color Cycle mode.

Double-click to disconnect the current Bluetooth device.

Long press for 3 seconds to enter light color selection mode (rotate to choose color, single-click or wait 3 seconds to confirm).

② USB Charging/Data Port

③ Function Button:

Single-click: Play/Pause

Double-click: Next track

Triple-click: Previous track

Long press for 2 seconds: Mute/Unmute

④ Power Switch

⑤ Top Cover:

Clockwise rotation to increase volume; counter clockwise rotation to decrease volume.

⑥ Power Indicator Light:

Low battery: Red light flashing

Charging: Green light steady

Fully charged: Green light off


Specifications

Material	Zinc Alloy
Connection Method	Bluetooth/USB
Bluetooth Connection Range	≥10m
Lighting Modes	Constant Light Mode/Light Off Mode/Auto-Off after 5 Seconds of Inactivity/Colorful Changing Mode
Lighting Colors	RGB
Battery Capacity	750mAh
Functions	Volume Up/Down; Previous Track; Next Track; Play/Pause; Mute/Unmute

Package Contents



VOL20 Volume Control Knob



USB-C Cable



User Manual

Operation Guide

1. Flip the power switch on the bottom of VOL20 to turn it on. The ambient light will blink blue. Proceed to step 2 if using USB mode, or step 3 if using Bluetooth mode.
2. USB Mode: Use the provided USB cable to connect VOL20 to your main device (like a computer). The ambient light on VOL20 will remain steady.
3. Turn on Bluetooth on your main device (phone/computer, etc.), search for "VOL20," and click to connect.
4. Choose the light mode and color, then adjust the volume of your main device to your preference.

Frequently Asked Questions

1. After turning on the power switch at the bottom of VOL20, why isn't the ambient light turning on?

A. It may be due to VOL20 being low on battery. Please recharge it before use.

B. It may be that the ambient light is currently turned off. Please click the light mode button to switch the light mode.

2. Why does the ambient light turn off after connecting VOL20 via Bluetooth or USB cable to the main device?

It may be that the ambient light is currently turned off. Please click the light mode button to switch the light mode.

3. My main device's Bluetooth shows connected to VOL20, but VOL20 does not respond when trying to control the main device?

It may be because double-clicking the light mode button disconnected VOL20 from its current connection state, but the main device has not updated its display. In this case, manually delete VOL20 from the main device and reconnect.

4. After using the mute function, other functions are disabled?

After muting VOL20, it enters a locked state and cannot use other functions. To unmute, you need to operate VOL20 directly. Alternatively, you can restart VOL20 to unmute.

5. How do I switch between Bluetooth and USB connection modes?

The USB connection mode takes priority over the Bluetooth connection mode by default. If you need to charge VOL20 while using Bluetooth mode, you can use a power strip or portable power source for power supply.

If you have any further questions, please contact our support team at **support@fosiaudio.com**.

Warranty and Maintenance

Fosi Audio pledges to give a 24-month limited warranty and support from the date of purchase. If you encounter any problem when using our product, please contact our support team at support@fosiaudio.com.

About Us

Fosi Audio designs and builds innovative audio products with all your music in mind. Great sound, simple but elegant designs, high-quality components, and truly useful features are what Fosi Audio pursues. We sincerely hope you can get as much enjoyment from our products as we've had to create them!

Our Website: www.fosiaudio.com

Amazon Store: www.amazon.com/fosiaudio

Facebook Page: www.facebook.com/fosiaudioglobal

Youtube Channel: www.youtube.com/@fosiaudio

Official Forum: <https://community.fosiaudio.com>

Whatsapp: +86 13716612254

After-Sales Service and Technical Support Email: support@fosiaudio.com





Get Online Support

产品简介

感谢您购买VOL20音量旋钮。

VOL20是一款支持蓝牙和USB两种模式连接的音量控制器。它采用坚固耐用的锌合金材质，并使用CNC技术精密加工，表面经过皮膜高温烤漆处理，具有出色的耐磨性和质感。内置的RGB可调氛围灯，供用户自由选择颜色和四种灯光模式。VOL20能够快速调节音量、远程控制音乐播放/暂停、上一曲和下一曲，并且即插即用，无需额外下载驱动或软件。使用VOL20，让桌面操作更加便捷和高效。



① 灯光模式键：

单击切换灯光模式：常亮模式/灯光关闭模式/无操作5秒熄灭模式/多彩变换模式
双击：断开当前蓝牙设备连接；
长按3秒：灯光颜色选择模式（通过旋转挑选颜色，单击或者静候三秒确定灯光颜色）

② USB充电/数据传输

④ 电源开关

③ 功能键：

单击：播放/暂停
双击：下一曲
三击：上一曲
长按2秒：静音/取消静音

⑤ 上盖：

顺时针旋转增加音量；逆时针旋转减小音量

⑥ 电源指示灯：

低电量红灯闪烁，充电时绿灯常亮，充满电绿灯熄灭


规格参数

材质	锌合金
连接方式	蓝牙/USB
蓝牙 连接距离	≥10m
灯光模式	常亮模式/灯光关闭模式/ 无操作5秒熄灭模式/多彩变换模式
灯光颜色	RGB
电池容量	750mAh
功能	加/减音量;上一曲;下一曲; 播放/暂停;静音/取消静音


配件清单



VOL20音量旋钮



USB-C线



说明书

使用说明

1. 拨动VOL20底部电源键开机, 此时氛围灯闪烁蓝色, 使用USB模式跳至第2步, 使用蓝牙模式则跳至第3步;
2. USB模式: 使用附带的USB线连接VOL20和要控制的主设备(如电脑), 此时VOL20氛围灯常亮。
3. 打开手机或者电脑等主设备蓝牙, 搜索“VOL20”并点击连接。
4. 选择灯光模式和灯光颜色, 即可开始随心调节主设备音量。

常见问题

1.VOL20底部电源打开后, 氛围灯没有亮起?

A.可能是VOL20电量耗尽了, 请充电后使用;

B.可能是灯光此时处于关闭状态, 请单击灯光模式键切换灯光模式。

2.主设备蓝牙或者USB线连接VOL20后氛围灯熄灭?

可能是灯光此时处于关闭状态, 请单击灯光模式键切换灯光模式。

3.主设备蓝牙中显示连接了VOL20但是使用VOL20控制主设备却无反应?

可能是因为双击灯光模式键断开了VOL20当前连接状态, 而主设备却没有更新显示状态, 此时需要在主设备手动删除VOL20后重新搜索连接。

4.使用静音功能后, 其他功能失效?

VOL20静音后VOL20会进入锁定状态, 无法使用其他功能, 解除静音仍需VOL20上操作。当然, 也可以通过重启VOL20来取消静音。

5.如何切换蓝牙和USB连接模式?

USB连接模式默认优先于蓝牙连接模式, 如果需要一边充电一边使用蓝牙模式, 可以使用电源排插或者移动电源进行供电。

如果您还有其他问题, 请联系我们的支持团队support@fosiaudio.com

产品保修

产品自售出7日内,在正常使用情况下出现故障,客户可以无条件退换货。正常使用两年内出现故障,可以免费保修。购买日期以发票或收据日期为准,网上购买按订单日期为准。

无法享受“三包”服务的情况:

1. 一切人为因素损坏,包括但不限于非正常工作环境下使用或者不按照说明书使用的;
2. 用户私自拆机、改装以及维修的;
3. 使用非指定或许可的配件造成损坏的;
4. 不能出示有效购机凭证的;
5. 不属于本公司产品的。

保修方式:

保修方式为送修,此条款只适用于官方销售渠道售出的产品,其他渠道请参考销售代理商的规

关于我们

深圳远虑科技是一家专注于音频产品的设计,研发和销售为一体的科技型公司。我们深耕用户需求,深入研发设计,通过不断创新,持续打磨产品和服务,致力于打造全球音频领域的星品牌。我们尤其在意客户的反馈,如果您有任何问题或者需求,欢迎联系我们。

官网: <https://www.fosiaudio.com>

天猫旗舰店: FOSI AUDIO旗舰店 fosiaudio.tmall.com

京东店铺: FOSI AUDIO旗舰店 mall.jd.com/index-12512168.html

QQ群: 760657010

售后邮箱: support@fosiaudio.com





扫码查看在线帮助

製品について

VOL20音量ツマミお買い上げいただきまして誠に有難うございました。

VOL20はBluetoothとUSB接続に対応した音量コントローラーです。丈夫で耐久性のある亜鉛合金を使用し、CNC技術を採用して精密加工され、表面は耐摩耗性と質感に優れた高温焼き付け塗装で処理されています。内蔵のRGB調整可能な雰囲気ライトにより、色とライトモードをお好みに選択できます。VOL20は、音量を素早く調整したり、音楽の再生/一時停止、前/次の曲をリモートで制御したりすることができ、追加のドライバーやソフトウェアをダウンロードする必要がなくプラグアンドプレイです。VOL20で、デスクトップ操作がより便利かつ効率的になります。



① 1.ライトモードボタン:

- ・一回押し込むとライトモードを切り替えます。(常時点灯/消灯/5秒間操作なし消灯/カラフル)
- ・ダブル押し込むと、Bluetoothペアリング解除します。
- ・3秒間押し続けると光色選択モードになります。(回転して色を選択、一回押し込むか3秒待つて光色を確定)

② USB充電/データ転送端子

③ 機能ボタン:

- ・一回押し込み: 再生/一時停止
- ・ダブル押し込み: 次の曲トリプルクリック: 前の曲
- ・2秒間押し続け: ミュート/ミュート解除

④ 電源スイッチ

⑤ 上部カバー:

時計回りに回すと音量が上がり、
反時計回りに回すと音量が下がります。

⑥ 電源指示ライト:

- ・バッテリー残量が不足の場合、赤色のライトが点滅;
- ・充電中は緑色のライトが点灯;
- ・完全に充電されると緑色のライトが消えます。


製品について

材質	亜鉛合金
接続方式	Bluetooth / USB
Bluetooth 距離	≧10m
ライトモード	常時点灯モード/消灯モード/ 5秒間操作なし消灯モード/カラフルモード
ライト色	RGB
バッテリー容量	750mAh
機能	音量の上げ/下げ、前/次の曲、再生/一時停止、 ミュート/ミュート解除


梱包詳細



VOL20音量ツマミ



USB-Cケーブル



マニュアル

操作ガイド

1. VOL20の底部にある電源スイッチをオンにすると、雰囲気ライトが青色に点滅します。
 - ・ USBモードは、手順②をご覧ください。
 - ・ Bluetooth モードは、手順③をご覧ください。
2. USB モード: 付属したUSB ケーブルで、VOL20 を制御対象の (PCなど) に接続します。この時、VOL20 の雰囲気ライトは常時点灯します。
3. スマホやPCなどのBluetoothをオンにし、「VOL20」を検索してペアリングします。
4. ライトモードとライトの色を選択し、お好みに合わせて音量を調整してください。

梱包詳細

1. VOL20底部の電源スイッチを「オン」にしても雰囲気ライトが点灯しません。

A. バッテリーが低下になった可能性があります。使用前に充電してください。

B. 雰囲気ライトが消灯モードになっている可能性があります。ライト モード ボタンを一回押し込むとライト モードを切り替えます。

2. デバイスを Bluetooth かUSB ケーブルで 本製品 (VOL 20) に接続すると、雰囲気ライトは消えます。

雰囲気ライトが消灯モードになっている可能性があります。ライトモードボタンを一回押し込むとライトモードを切り替えます。

3. デバイスの Bluetooth には本製品 (VOL 20) が接続されていることが表示されますが、VOL20 を使用してデバイスを制御しても応答がありません。

ライトモードボタンをダブル押し込むとVOL20の現在の接続状態が切断されるためかもしれませんが、デバイス側では表示状態が更新されていません。デバイス側で手動でVOL20を削除した後、再度接続を検索する必要があります。

4. ミュート機能を使用すると、他の機能が無効になりますか？

VOL20 をミュートすると、VOL20 はロック状態になり、他の機能が使えません。ミュートを解除するにはVOL20 で操作する必要があります。

5. Bluetooth 接続モードと USB 接続モードを切り替えるにはどうすればよいですか？

デフォルトでは、USB 接続モードが Bluetooth 接続モードよりも優先されます。充電中に Bluetooth モードを使用する必要がある場合は、電源タップかモバイル電源を使用できます。

まだ何かご不明な点がございましたら、弊社のサポートチームまでご連絡ください。
「support@fosiaudio.com」

製品保証

Fosi Audio は、購入日から 24 ヶ月の限定保証とサポートを提供することを約束します。製品の使用中に問題が発生した場合は、サポート担当 (support@fosiaudio.com) までご連絡ください。

当社について

Fosi Audio は、あらゆる音楽へのニーズを念頭に置いて革新的なオーディオ製品を設計、構築しております。素晴らしいサウンド、シンプルかつエレガントなデザイン、高品質のコンポーネント、そして本当に便利な機能こそが Fosi Audio の追求するものです。当社が作成したのと同じくらい当社の製品を楽しんでいただけることを心から願っています。

公式サイト：www.fosiaudio.com

Amazonストア：<https://www.amazon.co.jp/fosiaudio>

Facebook ページ：www.facebook.com/fosiaudioglobal

YouTube チャンネル：www.youtube.com/@fosiaudio

公式フォーラム：community.fosiaudio.com

ツイート (twitter)：https://twitter.com/FosiAudio_JP

アフターサービス電子メール：support@fosiaudio.com



オンラインサポートを受ける