


ifi UP TRAVEL

Quick Start Guide



1 Power

Power ON


Short press:
AUX 180°



2 TX Mode



3 RX Mode



4 'A' / 'B' Device Selector / B & Pairing



Short press: Cycle Selector

A + B > A > B

When switching, the corresponding LED blinks three times.



Long press ≥3s:  Pairing (RX)  Pairing (TX) 



Connect via phone:
Turn on 
select UP Travel.

5 TX/RX Mode Selector



< > Mode Switch: Swipe left/right

6 Codec Format Selector and LED / Voice Prompt/ A Pairing Factory Reset



Short press ≤1s:
Codec cycle

USB DAC

44.1-48kHz

88.2-96kHz

LED



SBC



AAC (RX only)



aptX



aptX HD



aptX Adaptive



LDAC



LHDC/HWA (RX only)

aptX Low Latency (TX only)



Long press ≥3s:

TX: A  Pairing 

RX: Voice Prompt ON

Long press ≥15s : Factory Reset



Nexis app

Ver1.0